

Transfer Case Verification

To Order, Please follow these easy steps:

1. Locate the transfer case tag assembly number. The transfer case tag is usually found on the rear case half. Examples are illustrated.

2. Look up the transfer case tag assembly number in the ReTech Transfer Case Catalog.

3. Contact your local ReTech Transfer Case Distributor for price and availability or call ReTech at 1-800-343-3557

New Process Assembly Tag



Chrysler numbers may also have 2 letters at the end of the 8 digit number

Late Model GM and Chrysler Assembly Tag



GM and Chrysler transfer case assembly numbers are an 8-digit number

Borg Warner Assembly Tag



Ford transfer case assembly numbers are a combination of 4 numbers and letters followed by a dash and 2 letters.

ATTENTION: ALWAYS REFER TO THE ASSEMBLY NUMBER TO ENSURE A POSITIVE IDENTIFICATION WHEN ORDERING!